

Hinson by DONGHIA
500 Bic Drive, Gate 1, Suite 200, Milford, CT 06461
Tel: 1-800-DONGHIA
www.donghia.com

HINSON

WALLPAPER HANGING INSTRUCTIONS (SCREEN PRINTED PAPER)

ABOUT THE PRODUCT:

This is a handmade print. Variations in prints and color will occur. Trim lines are for guidance. Trim to match design. Our wallcovering is manufactured by an exclusive process creating this unique look. Minor irregularities are to be expected as in any hand-crafted product.

BEFORE STARTING:

- Installation by a professional paperhanger is recommended. [see Wallcovering Installers Association at www.wallcoveringinstallers.org for assistance in finding a local installer]
- Inspect for defects before hanging. Check for correct design, color, shading and general quality. Also check quantity as additional rolls from this color lot may not be available. There is no guarantee of a 100% color match between lots.
- **NO CLAIMS, INCLUDING LABOR WILL BE ALLOWED AFTER GOODS ARE CUT OR HUNG.** If defects are discovered, please contact the dealer immediately.
- The following instructions must be followed and all care must be exercised by the installer while handling the material
- We suggest hanging 2 strips and then inspecting for any problems.

WALL PREPARATION:

- Remove all old wallpaper and adhesive and repair damaged wall areas to a smooth finish. All walls must be smooth, clean, and free of mold, mildew and stains. If necessary, apply a stain killing primer to prevent impurities from transferring to the wallpaper.
- The final choice of paste is the sole responsibility of the installer.
- The primer should be tinted to the same color as the background color of your wallpaper.

Hinson by DONGHIA
500 Bic Drive, Gate 1, Suite 200, Milford, CT 06461
Tel: 1-800-DONGHIA
www.donghia.com

HANGING YOUR NEW WALLCOVERING:

- **Use a sharp new blade, brass bound straightedge and zinc strip. Trim just into color. When trimming striped prints be sure the trimmed product has equal width stripes. Trimming along the edge of a dark colored stripe will aid in producing invisible seams.**
- **The use of a clear premixed adhesive works best with this product. Do not use clay-based adhesive! Wheat and cellulose adhesives are not recommended. A light weight clear paste is best.**
- **Use either a pasting machine or roller, apply an even coat of adhesive over the entire back of each strip of the wallcovering. Be sure edges are evenly and adequately covered. Book the pasted sheet and allow adequate soak time [about 5 minutes] before installing. Soak time is essential to allow the pasted sheet time to relax and expand in order to prevent bubbles, wrinkles, and possible shrinkage after drying. Use caution if rolling seams.**
- **Do not allow paste to get on the face of the wallcovering. If any should get on the face, remove at once with a damp, not wet sponge using a flicking action rather than scrubbing. Blot with a Turkish towel or soft cloth. Do not wipe. Do not allow paste to dry on face of wallcovering as permanent damage may occur. There may be some rub-off for dark colors.**